

Medium Format Fresnel lens assembling manual

Fresnel Lens



I'm Back®

I'm Back Sagl
Swiss Design - Made in China
www.imback.eu




www.imback.eu
Swiss design - Made in China

Attention: If your camera model is listed below in this “**Without Spring Section**”, the **Fresnel Lens** should be fixed on top of the **PDLC**:

- Mamiya 645 Pro: MA2
- Mamiya RB67: MA4
- Bronica ETRS: BR1
- Bronica SQa: BR2
- Bronica S2: BR3
- Hasselblad 500cm/Kiev88: HS1

Follow the steps:

1. Identify the **side with adhesive** of the **Fresnel Lens** and pay attention not to touch the surface of it. Handle it with clean, oil-free fingers, always holding it by the edges. **Note:** we suggest the use of a rubber glove.




2. Remove the plastic protection from the **Fresnel Lens** and place it precisely on the top of the **PDLC**. **Note:** there is a strong glue on the **side with adhesive** of the **Fresnel Lens**, therefore be careful to not place it mistakenly.

Attention: If your camera model is listed below in this “**With Spring Section**”, the **Fresnel Lens** should be attached beneath the **PDLC**:


- Mamiya 645 J-1000: MA1
- Mamiya C330: MA3
- Mamiya RZ67: MA5
- Pentax 645: PEN1
- Pentax 67: PEN2
- Rolleiflex f3.4/Yashica: RO1
- Rolleiflex 6006/7/8: RO2

1. Remove the existing **PDLC** carefully from your I'm BackMF adapter.



2. Place the double-sided adhesive on the **PDLC Frame Support**.

3. Identify the side with adhesive of the **Fresnel Lens** and pay attention not to touch the surface of it. Handle it with clean, oil-free fingers, always holding it by the edges. **Note:** we suggest the use of a rubber glove. Remove the plastic protection from the **Fresnel Lens** and place it precisely on the top of the **PDLC Frame Support**.



4. Place the **PDLC** precisely on the top of the **Fresnel Lens**. **Note:** there is a strong glue on the side with adhesive of the **Fresnel Lens**, therefore be careful to not place it mistakenly.

